

PRIVACY SPEAKER COVER INSTRUCTIONS

STEP 1

Ensure the cover will fit your chosen in-ceiling speaker.

Maximum Speaker Dimensions:

- Diameter up to 11"
- Height 8"
- Maximum Ceiling Cut out 8"

STEP 2

Install loudspeaker in ceiling, following the speaker manufacturer's installation instruction.

STEP 3

Place Privacy Speaker Cover over the loudspeaker. If working with tile bridge and rail, slit the cover to fit over the hanger bars.

Cut four slits with a size up to 1" max.

SLITS EXCEEDING 1" ARE NOT PERMITTED!

STEP 4

The wire can be fed through one of the cover vent holes located at the top. Follow the speaker manufacturer instructions to make proper connections.

STEP 4

Put the cover on top of the loudspeaker. Check for secure fit, and make sure the cover overhangs the hanger bars (if working with tile bridge and rail). The Privacy Speaker Cover must fit flush with the back asurface of the drywall board.

Intertek

